

## COMDIAL®

### DX-80

|   |
|---|
| <p><b>INSTRUCTIONS FOR<br/>PROGRAMMING SYSTEM CLOCK</b></p> |
|---|

- 1) Depress FEATURE # \* (this gets you into the program)
- 2) Depress ##### (8 times-this is the password)
- 3) Screen will then display bksp show chg -- Depress SHOW
- 4) Depress 0814 (this gets you into the clock program)
- 5) Depress SAVE - display will now show - SYSTEM TIME
- 6) Depress SHOW - display will now show - YEAR
- 7) (if year is incorrect, depress chg, change the date, then depress save)
- 8) Depress NEXT - display will show - MONTH (if incorrect, change as in #6)
- 9) Depress NEXT - display will show - DAY (if incorrect, change as in #6)
- 10) Depress NEXT - display will show WEEKDAY (if incorrect, change as in #6)
- 11) Depress NEXT - display will show HOUR (if incorrect, change as in #6)
- 12) Depress NEXT - display will show MINUTE (if incorrect, change as in #6)